

# **BOWIE** **INDUSTRIES, INC**

*Bowie Aero-Mulcher*  
*SG50S/SG50L/LD90T*



Serial No.: \_\_\_\_\_

## Table of Contents

<b>GENERAL INFORMATION</b>	
1.1 Unpacking.....	3
1.2 Getting Started.....	3
<b>1. SPECIFICATIONS .....</b>	<b>4</b>
<b>2. DESCRIPTIONS</b>	
2.1 Feed System .....	5
2.2 Engine/Power Take-Off.....	5
2.3 Controls.....	5
2.4 Hydraulic System.....	8
2.5 Electrical System .....	8
2.6 Fan and Beater.....	9
2.7 Discharge.....	9
2.8 Asphalt Option.....	10
2.9 Trailer.....	10
<b>3. OPERATING INSTRUCTIONS</b>	
3.1 General.....	11
3.2 Starting Engine.....	11
3.3 Operating Tips.....	11
<b>4. MULCHING</b>	
4.1 Mulching.....	12
4.2 Storage & Winterization.....	12
<b>5. MAINTENANCE INSTRUCTIONS</b>	
5.1 General .....	13
5.2 Wheels & Tires.....	13
5.4 Maintenance/Inspection Schedule.....	14
<b>6. TROUBLESHOOTING</b>	
6.1 Engine.....	15
6.2 Discharge Spraying Chute.....	15
6.3. LD90 Feed Assembly.....	15
6.4 Asphalt System Option.....	15
<b>7. REPAIRS AND ADJUSTMENTS</b>	
7.1 Feed Chute.....	16
7.2 Feed Assembly.....	16
7.2a Hydraulic Installation.....	16
7.3 Fan & Beater Assembly.....	17
7.4 Discharge Spraying Chute.....	17
7.5a Trailer Running Gear.....	17
7.5b Trailer Wiring.....	17
7.6a Ignition System.....	18
7.6b Engines.....	18
7.6c Fuel System.....	18
7.6d Power Take-off.....	18
7.6e Alternator.....	18
7.6f Battery.....	18
7.6g Starter Motor.....	18
<b>8. MAINTENANCE LOG</b>	
8.1 Daily Inspection Check Sheet.....	19
8.2 Monthly Inspection Check Sheet.....	19
8.3 Semi-annual Inspection Check Sheet.....	19
<b>9. PARTSLIST</b>	
9.1 Models SG50S & SG50T.....	20
9.2 Model LD90T.....	21
9.3 Asphalt Option.....	24
<b>10. ASPHALT OPTION</b>	
10.1 Operating Instructions.....	25
<b>11. LIMITED WARRANTY .....</b>	
11.1 Warranty Registration.....	27

## Forward

**Bowie Industries, Inc.** wishes to thank you for your purchase of the **Bowie Aero-Mulcher**. It has been manufactured after many years of research and development. We are confident that your new **Bowie Aero-Mulcher** will give you unfaltering service for many years making you a proud and satisfied owner. In order for this to happen we strongly recommend that you read this manual very thoroughly and see that your **Bowie Aero-Mulcher** is used and maintained in a proper way.

If you have any further questions regarding your **Bowie Aero-Mulcher** contact your dealer. When contacting your dealer be sure to have the following information available:

- 1.) Unit Model Number
- 2.) Unit Serial Number
- 3.) Engine Serial Number
- 4.) Engine Spec. Number

These numbers are located on your machine in the following places:

### **SG50S and SG50T**

On the engine mounting plate and main frame.

### **LD90T**

On the tool box lid and the main frame

Our company is the leader in the erosion control and landscaping industry. To serve your needs a score of national and international distributors are there to assist you in the sale and service of Bowie Erosion Control and Landscaping Equipment.

## **Bowie Industries, Inc**

[www.bowieindustries.com](http://www.bowieindustries.com)

Owen Meyer, President  
Gary Meyer, VP/Engineer  
Bob Jones, Sales Manager  
Jimmy Terry, Parts Manager

Use this manual to familiarize yourself with the features of your new equipment


# Introduction

By following the operating instructions and doing proper maintenance of your **Bowie Aero-Mulcher**, it will give you years of reliable and dependable service. So be sure that you read and carefully follow the instructions given in this manual. This manual provides information to models SG50S, SG50T, and LD90T **Bowie Aero-Mulcher**

## ***Bowie Industries, Inc.***

RESERVES THE RIGHT TO MAKE CHANGES IN DESIGN AND SPECIFICATIONS WITHOUT NOTICE.

### ***READ CAREFULLY ALL THE INSTRUCTIONS***



#### **1.1 Unpacking**

Your new **Bowie Aero-Mulcher** is shipped fully assembled, except that the battery will be disconnected. However make sure that prior to starting that all packaging materials are removed.



#### **1.2 Getting Started**

Perform the following operations:


- 1. *Read* Operation Manual
- 2. Check engine oil level
- 3. Fill fuel tank
- 4. Trailer models tighten wheel lug nuts
- 5. Install and connect the battery

# Specifications


## Section 1



**SG50S**



**SG50T**




**LD90T**

**Descriptions**  
**Section 2**

**2.1 Feed System**

Models SG50S and SG50T are equipped with a feed chute which require manual effort to push straw or hay into the beater chamber.

Model LD90T is equipped with a hydraulic powered feed assembly for feeding the beater chamber



**2.2 Engine and Power Take-Off**


Models SG50S and SG50T are powered by an air cooled, W-4, 35 HP. gasoline engine directly coupled to the shredder system.


Model LD90T is powered by a John Deere Model 4045T water cooled, 115 HP. diesel engine. The engine drives the system through a power take-off.

**2.3 Controls**

Models SG50S and SG50T controls are; throttle, choke, starter switch and ignition switch

Model LD90T controls are; throttle, choke, starter switch and ignition switch. In addition to these controls there are controls for the automatic feed and the power take-off clutch. Both of these controls are located within easy reach of the operator when seated.






**SG50S/SSG50T CONTROL PANEL**




**SG50S/SG50T CONTROL PANEL WIRING**

**Fig 2.3a**



**LD90T CONTROL PANEL**

**Fig. 2.3b**




**Fig. 2.2c**

**LD90T CONTROL PANEL WIRING**

## 2.4 Hydraulic System

Model LD90T is equipped with a hydraulic system to power the feed assembly. It consists of a belt driven manually controlled pump, reservoir, drive motor, and necessary connections.




**Fig. 2.4**

## 2.5 Electrical System

Engine ignition and gauges (Fig. 2.3a, Fig. 2.3b)

Trailer mounted systems the running lights



**Fig. 2.5  
Trailer Wiring**

Lights & Brakes-All Trailer Mounted Models



## 2.6 Fan and Beater

The fan and beater assemblies consists of a large fan and shaft (Fig. 2.6, ref. 7,10,11,12) to which hay and straw beater sets are attached. Models SG50S and SG50T are equipped with three sets of beaters. The fan and shredder assemblies on these models are direct coupled to the engine. Model LD90T is equipped with four sets of beaters. This model is equipped with a large pulley, which is belt driven from a power take-off.




Fig. 2.6

## 2.7 Discharge

The discharge spraying chute rotates (Fig. 2.6, ref. 1, 2) in a full circle and can be elevated up to 65 degrees. Model LD90T includes a seat with safety belt for the spraying operator.

## 2.8 Asphalt Option

This option has a belt driven pump which will move asphalt from a separate supply, such as an adjacent vehicle through a large gate valve, the pump, and a ball control valve through either one or two nozzles at the end of the discharge spraying chute





Fig. 2.8

## 2.9 Trailer

Trailer mounted units are on a single axle trailer with pneumatic tires and D.O.T. specified running lights. Low profile suspension and heavy-duty hubs equipped with grease packed tapered roller bearings. Breakaway safety switch.



Breakaway Switch

Fig. 2.9

## Operating Instructions Section 3

### 3.1 General

Locate all controls, gauges, the feed chute, and/or feed mechanism (Fig. 2.3a, Fig. 2.3b, Fig. 2.6). Perform the required maintenance (see section 5). Check to be sure that the fan chamber is clear of foreign objects, such as parts boxes that may have been stored during shipment

### 3.2 Starting Engine

Models SG50S and SG50T have an ignition switch and a starter switch (Fig. 2.3a). Pull out ignition switch, set choke and throttle then press the starter switch. After starting adjust throttle and choke settings.

Model LD90T has a key start ignition switch (Fig. 2.3b) as well as a low oil/high temperature shut off protection switch. To start set the throttle and choke, press in override switch button and hold while turning the key start. Continue to press in override button approximately 5 to 10 seconds until oil pressure rises. Allow engine to warm up at a fast idle. Set engine speed at 2500 RPM for normal operations.

### 3.3 Operating Tips

#### 3.3a Manpower

Two persons (excluding vehicle driver) can operate the Bowie Aero-Mulcher. A greater degree of efficiency can be achieved using more than two people' i.e. an operator, bale placement on chute, cutting and removal of wire or twine from bales.

#### 3.3b Safety

Everyone with the exception of the operator should be located in front of the **Bowie Aero-Mulcher**.

#### 3.3c Towing

The standard unit is equipped with a 2-5/16" ball hitch. Some units are equipped with an optional lunette eye with a pintle hook.



### WARNING!

- ⇒ Always secure close coupler on ball
- ⇒ Always secure hitch pin and retainer
- ⇒ Never tow over 30 MPH with tongue extended
- ⇒ Always connect safety chain to towing vehicle & breakaway switch
- ⇒ Use only Class IV 2-15/16" ball manufactured by Hammerblow or Bulldog

## **Mulching Section 4**

### **4.1 Mulching**

Models SG50S and SG50T have a manual feed system.

Model LD90T is equipped with an automatic power feed system. Before beginning mulching operations unlock the discharge extension support and deploy the feed ramp extension support and deploy the feed ramp extension. Then proceed as follows:

1. Set bale of material on ramp. Cut wires or twine and remove from bale
2. Model LD90T engage engine clutch. Engage automatic feed system by moving control handle forward located on the left-hand side of the operator. The further forward the handle is moved the faster the feed will operate. Reverse by pulling control handle to the rear.
3. Move material bale forward toward beater chamber. Maintain constant flow of material to chamber for optimum efficiency.
- 4  
. Direct discharge-spraying chute toward area to be treated applying with an up down, side to side motion.

### **4.2 Preparation for Storage & Winterization**

#### **Short Term Storage (periods of less than a month)**

1. Park and chock wheels to prevent inadvertent movement.
2. Disconnect battery cables. Model LD90T remove key.
3. In cold weather remove battery and store in warm dry place.

#### **Long Term Storage (periods greater than one month)**

1. Fill fuel tank and mix fuel with a fuel stabilizer
2. Remove battery
3. Cover machine in enclosure or with a tarp

#### **Winterization**

1. Change engine oil to proper weight and grade
2. Drain and fill radiator with proper mixture of ethylene and glycol and water.



## **Maintenance Instructions**

### **Section 5**

#### 5.1 General

Following the maintenance schedule and procedures outlined herein along with periodic inspections your **Bowie Aero-Mulcher** will give you trouble free operations. This section of your manual includes:

- |   |                     |
|---|---------------------|
| 5.2 Maintenance instructions and schedule | 8.1 Maintenance log |
| 6.1 Trouble shooting guide                | 9.1 Parts list      |
| 7.1 Repairs and Adjustments               | 10.1 Asphalt option |

#### 5.2 Maintenance Instructions

##### 5.2a Cleaning

It is necessary to keep the unit clean. Washing as needed. Frequently changing the engine oil and oil filters, air filters, and hydraulic filters when under dusty conditions. Keep the engine area free from straw, hay or other debris.

##### 5.2b Wheel torque requirements


It is extremely important to apply and maintain proper wheel mounting torque on your trailer axle. Torque is a measure of the amount of tightening applied to a fastener (nut or bolt) and is expressed as length times force. A force of 90 pounds applied at the end of a wrench one-foot long will yield 90 lb-ft of torque. Torque wrenches are the best method to assure that the proper amount of torque is being applied to the fastener.

**Note: Wheel nuts or bolts must be applied and maintained at the proper torque levels to prevent loose wheels, broken studs, and possible dangerous separation of wheels from your axle.**

Be sure to use only the fasteners matched to the cone angle of your wheel (usually 60° or 90°). The proper procedure for attaching your wheels is as follows:

1. Start all bolts or nuts by hand to prevent cross threading.
2. Tighten bolts or nuts in the sequence illustrated in Fig. 5.2
3. The tightening of the fasteners should be done in stages. Following the recommended sequence:
  - 1.) Tighten all the fasteners to 20-25 lb-ft,
  - 2.) Then to 50-60 lb-ft, and finally to 85-95 lb-ft.
4. Wheel nut/bolts should be torqued before first road use and after each wheel removal. Check and re-torque after the first 25 miles and again at 75 miles. Check periodically thereafter.

WARNING: DO NOT ATTEMPT TO REPAIR OR MODIFY A WHEEL. EVEN MINOR MODIFICATIONS CAN HAVE A GREAT EFFECT. DO NOT INSTALL A TUBE TO CORRECT A LEAK THROUGH THE RIM. IF THE RIM IS CRACKED, THE AIR PRESSURE IN THE TUBE MAY CAUSE THE PIECES OF THE RIM TO EXPLODE WITH GREAT FORCE AND CAN CAUSE SERIOUS INJURY OR DEATH



**Fig. 5.2**

##### 5.2c Tires

Before mounting tires onto wheels make certain that the rim size and contour is approved for the tire as shown in the Tire and Rim Association Yearbook or the tire manufactures catalog. Also make sure that the tire will carry the rate load.

## 5.4 Maintenance Schedule

Maintenance/Inspection Schedule	Daily	Monthly	Semi-Annual
Air Cleaner/Filter Check Change			
Battery and Connections			
Beater Chains			
Belt Tension			
Breakaway, Trailer (inspect)			
Chassis (inspect)			
Control Cable Linkage (adjust)			
Engine * (maintenance as specified in engine mfg. manual)			
Engine Belt Tension			
Engine Coolant (LD90T) Check Change			
Engine Mounts (inspect)			
Engine Oil and Oil Filter Check Change			
Feed Chain			
Fuel Check			
Fuel Filter Drain Water Change			
Grease All Fittings			
Hitch, Trailer (inspect)			
Hydraulic Oil (LD90T) Check Change			
Hydraulic Oil Filter Change			
Hydraulic System (inspect)			
Lights, Trailer (inspect)			
P.T.O. Power Take-Off * (maintenance in mfg. manual)			
Tires Inflation/Damage			
Wheel Bearings Re-pack			
Wheel Lugs Torque (inspect)			

- **These manuals are provided by the manufacture. The specifications and instructions in these manuals are to be followed for the specific parts. A failure to do so could result in voiding the manufacturer's warranty**

## Trouble Shooting Section 6

TROUBLE	PROBABLE CAUSE	CHECKOUT PROCEDURE AND REMEDIAL ACTION
<b>6.1 ENGINE</b>		
1. Engine will not crank	low battery	check battery charge or replace
	faulty starter switch	check and replace if needed
	faulty starter switch	check and replace if needed
	faulty started solenoid	check and replace if needed
	faulty starter motor	check and replace if needed
2. Engine cranks but won't start	improper throttle or choke settings	Adjust settings per engine starting instructions
	low pressure override button not depressed	Keep button depressed 5 to 10 seconds until oil pressure rises
	no fuel to engine	check fuel supply- clogged fuel filter or line, replace or flush
	no spark to engine	check for fouled spark plug, clean & reset gap or replace. Check distributor wires to plugs, repair or replace faulty wires
3. Engine runs rough or cuts out intermittently	fuel supply	clogged filter or lines, replace or flush as needed
	dirty or faulty carburetor	clean and/or adjust or replace
	dirty air cleaner	clean or replace element
	faulty spark plug or plug wires	check plugs, clean and reset gap or replace; faulty wires replace
	intermittent short in ignition wiring	perform continuity check of wiring, repair or replace defects
	faulty engine valve or cylinder ring	see manufactures engine manual
4. Battery will not maintain a charge	dead cell or short across cells	check and replace if needed
	faulty alternator or voltage regulator	check and replace if needed
<b>6.2 DISCHARGE CHUTE</b>		
1. Lacking volume or velocity (range)	too slow bale feed rate	improve feed rate
	beater chains faulty	replace
	fan drive belt slipping	adjust belt tension
	fan drive key sheared	replace with <i>genuine Bowie</i> part
2. Stiff rotation of spraying chute	turret bearings dragging	lubricate bearings
	turret bearings faulty	replace
<b>6.3 FEED ASSEMBLY LD90T</b>		
1. Feed system will not start	control lever linkage	adjust linkage
	broken chain or sheared sprocket drive key	check and replace faulty part with <i>genuine Bowie</i> component
2. Slow feed rate	control lever linkage	adjust linkage
	low motor RPM	pump belt drive slipping, adjust
		hose or fitting leaking, tighten or replace
3. Noisy fees		internal pump leakage, replace pump
		internal motor leakage, replace motor
	loose or worn chain and/or drag teeth	adjust chain tension or replace tighten or replace drag teeth
<b>6.4 ASPHALT SYSTEM (OPTION)</b>		
1. Asphalt will not flow	control linkage	adjust linkage
	clogged lines	check and clean out
2. Asphalt flow range or volume low	supply valve partially open	fully open valve
	line from supply clogged	check and clean out
	pump drive clutch slipping	adjust or replace
	control valve clogged or partially open	check and clean out, open fully
	pump pressure or volume not adequate	check out, repair or replace



## Repairs & Adjustments

### Section 7



### **WARNING!**

**Turn off engine and disconnect the battery before working on the fan or beater**

#### **7.1 Feed Chute - Models SG50S and SG50T**

Repair of the feed chute consists of merely replacing of the pivot pins for the extension, removing dents which prevents smooth movement of the bales into the fan and beater chamber, and paint touch up for the prevention of corrosion. The shredder assembly does not require assembly

#### **7.2 Feed Assembly - Model LD90T (Fig. 2.1)**

The feed assembly is a hydraulic powered chain drive. The four adjusting bolt assemblies (ref. 1) may adjust tension

Replacement of the chains (ref. 5) may be necessary when the chain is worn or stretches so that it no longer stays on the sprockets.

All sprockets are keyed to their respective shafts. If a key shears, be sure that the replacement is a *genuine Bowie* part. It must fit snug into both the shaft and the sprocket.

Replacement of drag teeth (ref. 3) is necessary from time to time. A small inventory of spares should be maintained

Pillow block bearings (ref. 2) are long lasting if properly maintained. When necessary replacements should be made.

#### **7.2a Hydraulic Installation**

The hydraulic installation provides power for the feed assembly

Setting tension of pump drive belt is by way of adjustment of the idler pulley. Replace the belt if worn, frayed, or split. A small inventory of spares should be maintained.

Replace filter (ref. 7) according to Maintenance/Inspection Schedule.

Service the reservoir (ref. 8) with hydraulic oil having the viscosity of 200 SSU @ 100° F or better.

Remove and replace hose assemblies whenever an inspection indicated damage or fraying.

The pump (ref. 9) and the motor (ref. 6) should require no maintenance unless the speed of the feed is noticeably slower. This may indicate that internal leakage is being experienced. In such a case the defective component needs to be repaired or replaced.

The crossover relief valve (ref. 5) is factory preset for proper pressure and should not be adjusted. If a significant shock is noticed when feed is reversed it may be that one of the valve poppets has become stuck. Remove the valve and clean it or replace it.

**Note: When draining the reservoir, drain all hoses as well and replace the filter element.**



## **WARNING!**

**Turn off engine and disconnect the battery before working on the fan or beater**

### **7.3 Fan and Beater Assembly (Fig. 2.6, ref. 10,11)**

The fan and beater assemblies are similar on all models of the **Bowie Aero-Mulcher**. Models SG50S and SG50T are driven directly from the engine through a flexible coupling. Model LD90T is by a belt driven pulley assembly by the power take-off.

The belt tension on Model LD90T is set by adjustment of the idler pulley located between the power take-off and the fan shaft mounted pulley.

Replace the beater sets whenever discharge appears to less than normal. An inventory of spare beater sets should be maintained.

Pillow blocks (Fig. 2.6, ref. 7) are long lasting if properly maintained. When necessary replacements should be made. We recommend that spares should be kept on hand.

If the fan (Fig. 2.6, ref. 10) becomes loose on the shaft or fails to turn at all. Replace the drive key with a *genuine Bowie* part. Be sure that it fits snug in both the shaft and the fan.

### **7.4 Discharge Spraying Chute (Fig. 2.6, ref. 1)**

The discharge-spraying chute functions in the same manner on all units. Model LD90T is equipped with a seat for the operator, most controls and the control panel is located on the assembly.

Other than an occasional control cable linkage adjustment on Model LD90T and lubrication of the turret bearing assembly (Fig. 2.6, ref. 2) no other maintenance should be necessary.

Control panel schematic and control locations (Fig. 2.3b)

### **7.5a Trailer Running Gear**

All trailer mounted systems of the **Bowie Aero-Mulcher** incorporate conventional trailer hubs, electric brakes, electric breakaway switch, tires and wheels.

Use a good grade of axle grease when re-packing the hubs. If bearings need replacement see replacement parts under Section 9 of this manual.

Replacing tires use only the correct specified size.

See Maintenance/Inspection schedule in Section 5 of this manual for further instructions regarding the running gear.

### **7.5b Trailer Wiring (Fig. 2.3)**

All trailer mounted systems of the **Bowie Aero-Mulcher** incorporate a conventional wiring system for taillights, turn signals, stop lights, brakes and breakaway switch.

Replace defective lights

Repair or replace cut or damaged wiring, connectors, and/or faulty breakaway switches (Fig. 2.5, Fig. 2.9)

### 7.6a Ignition System

Model SG50S and SG50T have a very reliable ignition system of which need no adjustments. Repair procedure consists primarily of removal and replacement of the defective part. Removal and replacement repair the battery, ignition switch, and starter button.

Model LD90T ignition systems incorporate a 'Murphy' switch (Fig. 2.3b, ref. 7). This switch shuts off the engine when conditions such as low oil pressure or high engine temperatures exist. This ignition system is conventional and reliable. No adjustments are necessary, as repair is limited to the removal and replacement of the defective part.

**NOTE: The starter motor, alternator, voltage regulator, and spark plugs are covered in the engine manufacturer manual**

### 7.6b Engines

Model SG50S and SG50T use a Wisconsin Model W4-1770 air-cooled engine. Repairs and adjustments are to be made following the engine manufacturers manual and instructions. Service the engine following the manufacturer instructions and the maintenance/inspection schedule in this manual.

Model LD90T uses a John Deere water-cooled, diesel engine. Repairs and adjustments are to be made following the engine manufacturers manual and instructions. Service the engine following the manufacturer instructions and the maintenance/inspection schedule in this manual.

### 7.6c Fuel System

All models incorporated a tank, ball valve, fuel line, fuel pump, and fuel filter. Use clean containers for fuel. Replace fuel filter as set forth in the maintenance/inspection schedule located in section 5 of this manual.

### 7.6d Power Take-Off

Model LD90T is equipped with a power take-off assembly. Repairs and adjustments are to be made following the manufacturers manual and recommendations. Service the power take-off assembly as set forth in the maintenance/inspection schedule located in section 5 of this manual.

### 7.6e Alternator

All models have an alternator mounted to the engine. Should it malfunction, replace with a new or rebuilt unit.

### 7.6f Battery

The battery is an automotive type. If the **Bowie Aero-Mulcher** is to be idle for a period of time then disconnect. When a replacement is needed replace with an equal CCA rating.

### 7.6g Starter Motor

Should the starter motor malfunction, replace with a new or rebuilt unit.

**Maintenance Log**  
**Section 8**

**8.1 Daily Inspection Check List**

INSPECT DAILY	AIR FILTER /CLEANER	BEATER CHAINS	BELT TENSION	CONTROL LINKAGE	ENGINE BELT TENSION
Date					
Hours					

INSPECT DAILY	ENGINE OIL AND FILTER	FUEL CHECK	FUEL FILTER DRAIN WATER	GREASE AND LUBRICATION	HYDRAULIC OIL CHECK	TRAILER BREAKAWAY
Date						
Hours						

INSPECT DAILY	INSPECT TRAILER HITCH	INSPECT TRAILER LIGHTS	INSPECT TIRE INFLATION DAMAGE	INSPECT WHEEL LUGS
Date				
Hours				

**8.2 Monthly Inspection Check List**

INSPECT MONTHLY	ADJUST FEED CHAIN TENSION	AIR FILTER/ CLEANER CHANGE	BATTERY & CONNECTIONS	ENGINE OIL & FILTER CHANGE	FUEL FILTER CHANGE
Date					
Hours					

INSPECT MONTHLY	HYDRAULIC * OIL CHANGE	HYDRAULIC * OIL FILTER CHANGE	INSPECT TRAILER BREAKAWAY	INSPECT TRAILER LIGHTS	TIRES INFLATION/DAMAGE
Date					
Hours					

**8.3 Semi-Annual Check List**

SEMI-ANNUAL INSPECTION	INSPECT CHASSIS	CHANGE ENGINE COOLANT *	INSPECT ENGINE MOUNTS	INSPECT HYDRAULIC SYSTEM *	HYDRAULIC OIL FILTER CHANGE *	HYDRAULIC OIL CHANGE *	WHEEL BEARINGS REPACK
Date							
Hours							

\*Model LD90T only

## Parts List Section 9

### 9.1 Parts for Models SG50S & SG50T 12/18/00

LOCATION	DESCRIPTION	PART REFERENCE
<b>CONTROL PANEL</b>	AMP METER STARTER SWITCH DECAL SET HORN HORN BUTTON INSTRUMENT PANEL COMPLETE ASSEMBLY SWITCH, IGNITION PUSH-PULL CHOKE, CABLE THROTTLE CABLE HOUR METER INSTRUMENT PANEL GAUGE	EC A355 WISC YC10C/ ECA356 EC A1800C EC1006 W/P EC1990A EC A206 EC1989/ ECA353 EC A354 EC A351-30 EC A352/EC4049 EC A2061
<b>DISCHARGE SPRAY</b>	HANDLE, RIGHT HAND HANDLE, LEFT HAND NUT, TURNBUCKLE TURNBUCKLE DISCHARGE NOZZLE ASSEMBLY 1-1/4" YELLOW HANDLE GRIP  * DISCHARGE EXTENSION OPTION: 2' 3' 4'	EC A204-3 EC A204-3A EC S35-4A EC A204-4 EC A204 EC S35-3B EC S352 EC S353 EC S355
<b>ENGINE</b>	* ALL PARTS (W4-1770 IN MFG'RS PART BOOK) DRY AIR CLEANER ENGINE WIRING HARNESS FUEL STRAINER, WISCONSIN GUARD, COUPLING COVER OIL FILTER (WISCONSIN RV52) MUFFLER PLUG PRE CLEANER PUMP, WISCONSIN ELECTRIC FUEL ROTATING SCREEN RUBBER COATED WASHER 9/32 SCREW 1/4-20-3/4 (ROTATING SCREEN)	WE L0115A EC A357W WE LP43 EC A202 — WE WD72 WE PF144 WE L0176 WE LP63 WE SE204D WE PH442 WE XA104

<b>FAN &amp; BEATER ASSEMBLY</b>	1/2 X 3 SAE (#602 HEAD) BOLT 1/2 X 2 SAE GR8 BOLT 1/2 SAE LOCK NUT 10-24 NYLON INSERT LOCK NUT 12" GREASE LINE BEATER CHAIN (4 LINK) BEATER CHAIN ASSEMBLY (6 PER SET) BEATER BRACKET BOLTS COMPLETE ASSEMBLY COUPLING, COMPLETE MORFLEX FAN, 22-5/8" FLEXIBLE SECTION OF COUPLING HUB, FAN SHAFT COUPLING HALF HUB, COUPLING HALF ENGINE SHAFT HUB, MORFLEX KEY, FAN LUG, LIFTING PILLOW BLOCK W/BEARING TYPE E 1-3/4" PIN (1/2 ROD 1/2 LONG) SCREW, SET SHAFT, FAN	EC 305-4 EC S30-2 EC 305-5 EC S30-2A EC 1021 EC S30-1 EC S30-8 EC S30-3 EC A305-4 EC A215 EC A305C EC A303 EC A305-3 EC A305-1 EC A305-2 * EC A305-2 * EC A303-1 EC A203 EC A302 EC S30-3A EC A303-2 EC A301
<b>FUEL</b>	1/4 BALL VALVE LINE, FUEL PUMP BRACKET TANK CAP TANK	EC A219 EC A220 EC L63B EC 1888 EC A218
<b>TRAILER</b>	12X2 ELECTRIC BRAKE ASSEMBLY 16X6 -8 HOLE WHEEL 7.50-16 10 PLY TIRE (NOT FOR RESALE) BRAKE PLATE BACK ASSEMBLY BREAKAWAY SWITCH CABLE ASSEMBLY, LIGHTS & BRAKES CHAIN, SAFETY 10' HIGH TEST W/HOOK COMBINATION STOP/TAIL LIGHT FENDER, RIGHT FENDER, LEFT HITCH, BALL TYPE TELESCOPING HITCH, PINTLE TYPE TELESCOPING HITCH, PIN & RETAINER (SET) HUB, BEARING CONE INNER BEARING HUB, DRUM CONE OUTER BEARING HUB, DRUM COTTER PIN 1/8X2 HUB, DRUM DUST CAP E-Z PLUG TYPE HUB, DRUM OUTER BEARING HUB, DRUM 1" SPINDLE NUT HUB, DRUM COMPLETE ASSEMBLY HUB, DRUM 1" SPINDLE WASHER HUB, DRUM INNER BEARING HUB, DRUM GREASE SEAL JACK ASSEMBLY LENS, STOP/TAIL LIGHT LICENSE PLATE BRACKET LUG BOLT 1/2X1-7/8 LUG BOLT 1/2X2-3/4 LUG NUT 1/2 STUD & LUG NUT SET (8)	EC 3120/ECA378 EC A213 EC A378* EC A345/EC1993 EC A346 EC A343 EC 1839 EC A210R EC A210L EC A209 EC A344 EC A342 EC A326 EC A327 EC A324 EC S387 EC A329 EC A318 EC A212 EC A319 EC A328 EC A330 EC A341 EC 1839A EC 1846 EC A332A EC AS381A EC S386 EC A332
<b>TURRET BEARING ASSEMBLY</b>	BEARINGS (SET) COMPLETE ASSEMBLY FITTING, LUBRICATION RACE, LOWER RACE, UPPER SEAL, O'RING	EC A253 EC A250 EC A255 EC A252 EC A251 EC A254

**\* Asphalt option parts list see 9.3**

## 9.2 Parts for LD90T 12/18/00

LOCATION	DESCRIPTION	PART REFERENCE
CONTROL PANEL	AMP METER	EC S50-4
	HORN	EC S50-15
	HORN BUTTON	EC S50-5
	KEY, SWITCH	EC S50-6
	OIL PRESSURE	EC S50-2
	OVERRIDE (MURPHY) SWITCH	EC S50-7
	PANEL	EC S390
	TACHOMETER	EC S50-1
DISCHARGE SPRAY	WATER TEMPERATURE	EC S50-3
	BRACKET, PIN & KEY	EC S35-9
	BRACKET, DISCHARGE STOWING	EC S35-10
	COUNTERBALANCE	EC S35-12
	DISCHARGE SPRAYING ASSEMBLY	EC S35
	DISCHARGE EXTENSION, HINGE	EC S35-2
	DISCHARGE, EXTENSION	EC S35-1
	DISCHARGE, ELBOW	EC S35-6
	HANDLE, RIGHT HAND	EC S35-3
	HANDLE, LEFT HAND	EC S35-3
	SEAL, ELBOW SIDE	EC S35-6B
	SEAL, LOWER ELBOW	EC S35-6A
	SEAT	EC S35-5
	SEAT BELT ASSEMBLY	EC S35-5B
	SEAT, ADJUSTMENT SLIDE	EC S35-5A
TURNBUCKLE	EC S35-4	
TURNBUCKLE, NUT	EC S35-4A	
ENGINE	1700 SCREEN-O-MATIC	EC S30-11
	20" X4 EXHAUST PIPE	
	38' X4 FLEX STEEL PIPE	
	4" MUFFLER CLAMPS	EC S10-54CP
	4/5VX1060 BANDED BELT	EC S30-6MD
	5 FIN RADIATOR	EC S40-8
	ALTERNATOR	EC S50-8
	CLUTCH PLATE	EC S90-15
	INJECTOR PUMP	EC S50-14
	JOHN DEERE TWISTLOCK THROTTLE CABLE	EC S35-A
	JOHN DEERE DIESEL W/O AUX. DRIVE	
	MURPHY OIL GAUGE	EC S50-11
	MURPHY TEMPERATURE GAUGE	EC S50-12
	OIL PRESSURE SENDER	EC S50-10
	POWER TAKE-OFF	EC S90-14
	SHEAVE 4/5V10.9 (FAN SHAFT)	EC S30-6C
	SHEAVE, 4/5V9.75 (MOTOR)	EC S39-C
	STARTER	EC S50-9
	TEMPERATURE SENDING UNIT	EC S50-13
	2 1/4" HUB	EC S30-6
FAN & BEATER ASSEMBLY	1/2 SAE GR 8 NYLON INSERT LOCK NUT	EC S30-2A
	1/2 SAE GR 8 BOLT	EC S30-2
	10-24 NYLON INSERT LOCK NUT	EC S30-2A
	17-61 IND-OT-20-CW-SW-STL, 2-7/16 BORE	EC S30-5
	5/8 X 6 STD BOLT (FAN SHAFT BOLTS)	EC S30-5B
	5/8 STD NUT (FAN SHAFT NUTS)	
	BEATER BRACKETS-SET COMPLETE	EC S30-8
	BEATER PIN	EC S30-3A
	BEATER CHAIN 4 LINK	EC S30-1
	BEATER CHAIN 5 LINK	EC S30-1B
	BEATER CHAIN 6 LINK	EC S30-1C
	E2-3/16" PILLOW BLOCK BEARING	EC S30-7
	FAN & BEATER ASSEMBLY	EC S30
	FAN COVER	EC S30-10
	FAN BOLT	EC S-5B
	FAN SHAFT	EC S30-4
	FAN	EC S30-5
	FAN KEY	EC S30-5A
	SUPPORT MEMBER	EC S30-9



<b>FEED ASSEMBLY</b>	#161S SWIVEL GEAR BOX (JACK) #60-M2 W/C CONNECTING LINK (CHAIN) 1" PILLOW BLOCK BEARING 10-24 X 1-1/4" SOCKET HEAD CAP SCREW 10-24 NL LOCK NUT ADJUSTING BOLT BOLT BRACKET, 'L' ADJUSTING CHAIN, REAR DRAG CHAIN, COUPLING CHAIN, FRONT DRAG CONTROL CABLE COUPLING KEY E1-7/16" PILLOW BLOCK BEARING 4/5V9.75 E1-7/16" HUB FEEDER PIVOT PIN IDLER ASSEMBLY TENSION FOR BELT IDLER SPROCKET LEVER ASSEMBLY PILLOW BLOCK W/BEARING RACK & POST (JACK COMPONENT) SHAFT, DRAG SHAFT, CENTER DRAG IDLER SPROCKET SHAFT, FRONT DRAG IDLER SPROCKET SPROCKET KEY SPROCKET COUPLING SPROCKET, IDLER SPROCKET, DRAG SPROCKET, FRONT DRIVE SPROCKET, FRONT DRAG IDLER TEETH, DRAG (6 EACH FOR SPARE)	EC S34167 EC S25-7 EC S25-3 EC S25-7A EC S25-7B EC S25-1A EC S-3A EC S25-1 EC S25-A EC S25-11 EC S25-4 EC S35-1B EC S25-11B EC S39-B EC S39-C EC S39-D EC S25-12 EC S39-C EC S25-5 EC S35-8 EC S25-3 EC S34110 EC S25-11C EC S25-6 EC S25-2A EC S25-6C EC S25-11A EC S25-5 EC S25-6A EC S25-6B EC S25-2 EC S25-8
<b>FUEL</b>	1/4 X 5/16 BRASS HOSE FITTING 1/4 X 4 STD BLACK NIPPLE 1/4" BALL VALVE BRASS GAS CAP W/GASKET FUEL LINE PUMP TANK	EC S219 EC1005 EC S376 EC S40-16 EC S377
<b>HYDRAULIC ASSEMBLY</b>	3/4" MAGNETIC DRAIN PLUG 3/4-2 WIRE HYDRAULIC HOSE W/FITTINGS BALL VALVE BELT, DRIVE CABLE ASSEMBLY CLEVIS GRENSON CROSSOVER RELIEF VALVE GRENSON 10 MICRON FILTER ASSEMBLY HCMSM-120 SIDE MOUNT FILLER BREATHER HOSE ASSEMBLY HOSE, SUCTION HOSE, PRESSURE HOSE, PRESSURE HOSE, CASE DRAIN HYDRAULICS DRIVELINE ASSEMBLY LENEL TEMPERATURE GAUGE MOTOR, ROSS HYDRAULIC PULLEY PUMP, VARIABLE VOLUME 15 SERIES RESERVOIR ASSEMBLY	EC S45-1E EC S45-A EC S45-2 EC S45-6B EC S35-7 EC S35-7A EC S45-7 EC S-3 EC S45-1A EC S45-B EC S45-D EC S45-A EC S45-B EC S45-C EC S45-1031A EC S45-1D EC S45-6 EC S45-6A EC S45-4 EC S45-1
<b>HYDRAULIC DRIVE LINE</b>	BEARING KIT 004-5-153X FLANGE 004-2-479 SLIPYOKE 004-2-3-128KT SPICER YOKE (LONGHORN) 2-4-433 TUBE YOKE 004-2-28-357 TUBING (2X.083)17" 004-16-30-62 SLIP STUB SHAFT 004-2-40-1031	EC S45-153 EC S45-479 EC S45-128 EC S45-433 EC S45-357 EC S45-62 EC S45-1031

<b>TRAILER</b>	12 X 2 ELECTRIC BRAKE ASSEMBLY	EC 3120
	16 X 6-8 HOLE WHEEL	EC S350
	750-16 TIRE 10 PLY (NOT FOR RESALE)	EC S349
	CABLE ASSEMBLY, LIGHTS & BRAKE	EC S347
	HAND BRAKE CONTROLLER	EC 3121
	HUB/DRUM ASSEMBLY	EC S382
	HUB/DRUM, COTTER PIN	EC S324
	HUB/DRUM, SPINDLE WASHER	EC S385
	HUB/DRUM, OUTER BEARING CONE	EC S384
	HUB/DRUM, DUST CAP	EC S387
	HUB/DRUM, PLUG	155400 RUBBER CAP
	HUB/DRUM, SEAL	EC S364
	HUB/DRUM, SPINDLE NUT	EC S386
	HUB/DRUM, INNER BEARING	EC S363
	JACK 198250SWL198	EC S351
	LICENSE PLATE BRACKET	EC 1846
	STOP/TAIL LIGHT COMBINATION CURB SIDE	EC 1834
	STOP/TAIL LIGHT COMBINATION ROAD SIDE	EC 1839
	TORFLEX AXLE ASSEMBLE	EC S365
	TONGUE ASSEMBLY, TELESCOPING HITCH	EC S360
	TONGUE ASSEMBLY, BALL TYPE	EC S383-1
	TONGUE ASSEMBLY, PIN & RETAINER HITCH (SET)	EC S342
	TONGUE ASSEMBLY, BREAKAWAY SWITCH	EC S345
	TONGUE ASSEMBLY, LUNETTE EYE OPTION	EC S383-2
	TONGUE ASSEMBLY, SAFETY CHAIN	EC S343
	CHAIN HOOK	EC 1025
		EC 1024
<b>TURRET BEARING ASSEMBLY</b>	BEARINGS (SET)	EC S35-13B
	COMPLETE ASSEMBLY	EC S389
	FITTING, LUBRICATION	EC S35-13C
	RACE, LOWER	EC S35-13
	RACE, UPPER	EC S35-13A
	SEAL, O'RING	EC S388

### 9.3 Asphalt Option Parts

<b>LOCATION</b>	<b>DESCRIPTION</b>	<b>PART REFERENCE</b>
ASPHALT SYSTEM	3/3V14.0 SHEAVE (PUMP) 7/8" HUB	EC S65-6B
	3/3V3.65 SHEAVE (SHAFT)	EC S65-6
	3/3X560 BANDED BELT	EC S65-5
	3/4" BALL VALVE	EC S65-1
	3/4" BRASS FLATJET SPRAYING NOZZLE	EC S65-3
	ASSEMBLY OPTION	EC S65
	BUSHING, 1-1/2" X 3/4"	EC S65-1E
	CLUTCH	EC S65-4
	COLLAR, 1-1/2"	EC S65-1D
	ELBOW, 1-1/2" STREET	EC S-1C
	ELBOW, 3/4" STREET	EC S65-1A
	NIPPLE, 1-1/2" X 6	EC S-1B
	TEE, 3/4"	EC S65-2

## ***Asphalt System (Option)*** ***Section 10***

### **10.1 Asphalt Option Instructions**


To operate asphalt system:

1. Hook up suction line to gate valve at rear of machine.
2. Open valve

To engage asphalt pump:

1. To engage pump open cover on pump sheave guard.
2. Locate bolt in clutch hub (Fig. 9.3)
3. Line up reference marks (Fig. 9.3) through hole in side of guard  
Marks are on outside edge of sheave and hub.
4. Tighten bolt in hub
5. To regulate pump pressure use ball valve located under beater chamber on the inside of  
working platform.
6. Asphalt flow shut-off valve is located on top of nozzle (Fig. 2.6, ref. 25)

**PUMP SHOULD ALWAYS BE DISENGAGED WHEN ASPHALT SYSTEM IS NOT IN USE.**



**Fig. 9.3**

## Limited Warranty

To effect warranty the warranty registration card must be filled out and returned **Bowie Industries, Inc.** within thirty days of purchase. No warranty is in effect without this card being returned to **Bowie Industries, Inc.**

New equipment warranty applies to original purchasers for a period of twelve months from date of purchase. Such equipment is warranted free from defects in materials and workmanship. Warranty does not extend to any equipment that had been damaged in accident or shipment, misuse, abuse, or modified by anyone other than **Bowie Industries, Inc.**

Your sole remedies under this warranty is limited to repairing or replacement of any part that is returned to **Bowie Industries, Inc.** or to a **Bowie Industries, Inc.** authorized dealer, freight prepaid. Returns for warranty needs to be accompanied with a return authorization number. Such repair or replacement to be made provided that defect is covered by warranty as determined by **Bowie Industries, Inc.**

**Warranty exclusions:** (1) normal maintenance and/or adjustments, (2) altered equipment, (3) engines, engine clutches, batteries, tires or other accessories that are subject to respective manufacturers warranties.

Except as expressly set forth above, no other warranties, either expressed or implied, are made with respect said equipment. **Bowie Industries, Inc.** expressly disclaims all warranties not stated herein. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

**Bowie Industries, Inc.** reserves the right to make changes in design and specifications without notice.



- ▶ Wear safety glasses
- ▶ Keep clear from beater chamber hands, feet, and clothing
- ▶ Don't operate equipment without safety guards in place
- ▶ Avoid obstacles when moving while unit is in operation
- ▶ Avoid driving on slopes
- ▶ **Always turn engine off and disconnect battery prior to servicing** beater chamber, feed chute, cleaning, lubricating or making adjustments to equipment
- ▶ Never direct discharge at people, buildings, power lines or equipment